



Utah Shed Mover

Shed Move Preparation Checklist

To ensure a smooth and efficient shed move, please review the following steps and provide the requested information before your scheduled service.

1. Clear the Shed Interior

- Remove all items from inside the shed, including portable shelves and loose flooring.
- Secure any built-in features that will remain in place.

2. Trim Surrounding Vegetation

- Trim back trees, bushes, and tall grass near the shed to allow room for access.
- Remove any low-hanging branches that could interfere with equipment.

3. Ensure Adequate Access

- Check for obstacles such as fences, gates, curbing, rocks, air conditioning units, or yard decor.
- If the shed is being moved to a different property, the access paths and gates (if applicable) must be at least 24 inches wider than the shed itself to allow room for maneuvering the shed.
- For moves within the same property, we only require a 4-foot-wide access gate to get our Shed Moving equipment into the backyard.
- Prepare the New Shed Site (if applicable)
- Ensure the new location is level, accessible, and free of debris.
- Mark or indicate exactly where you'd like the shed placed.

4. Provide Photos - Please send clear, well-lit photos of the following:

- Current shed location (front, back, and both sides)
- Access path to the shed (including gates, driveways, tight areas, etc.)
- New shed location (if moving across the yard or to a new property)
- Surrounding property (fences, trees, landscaping, utilities)
- Shed floor - specifically how the floor is constructed (underneath if possible) so we can assess if it's structurally sound for moving

Email photos to: info@UtahShedMover.com Or text them to: 801-509-5504

Please include you Name, Phone Number and the address(es) of the site location(s).

5. Be Available for Questions

- Make sure someone familiar with the property is available by phone in case we need help clarifying access or placement instructions.